SETUP ANDROID FOR SCANNING
Intent

Honeywell

Start settings and find Scan settings







Select Data processing settings. Set Suffix, check Scan To Intent and Data Intent





Under Data Intenet set action



Zebra

Find DataWedge







Disable Keystroke output, enable Intent output, set Intent action and set Intent delivery to broadcast.







Datalogic

Start settings and find Scan settings, Then find Wedge.





Disable keyboard wedge and enable intent wedge and setup intent delivery mode, intent action and intent category.

com.raptool.SCAN

android.intent.category.DEFAULT







Newland

Start Quick Settings and select Scan. Enable scan. Set Output Mode to API. Set Broadcast output settings as you can see on the screen (set broadcast action to com.raptool.SCAN, leave everything else as default).

